

INSTRUCTION SHEET


KEIHIN CARBURETOR

HONDA CIVIC (CVCC ENGINE)

50-523

GENERAL EXPLODED VIEW

THE GENERAL DESIGN AND PARTS SHOWN WILL VARY TO
INDIVIDUAL UNITS COVERED ON THIS INSTRUCTION SHEET



DISASSEMBLY

USE EXPLODED VIEW AS A GUIDE. THE NUMERICAL SEQUENCE
MAY GENERALLY BE FOLLOWED TO DISASSEMBLE UNIT FAR
ENOUGH TO PERMIT CLEANING AND INSPECTION. NOTE:
BEFORE REMOVING BOWL COVER, REMOVE EPOXY SEALER FROM
TOP OF NEEDLE SEAT SCREW HEADS. TO REMOVE FLOAT PINS
(35) (38) WHICH HAVE A PRESSED IN FIT. USE A PIN PUNCH
& SMALL HAMMER. CAREFULLY DRIVE PINS OUT FROM THE INSIDE
END WHICH HAS THE TAPERED PRESSED FIT. RECORD SIZES OF
JETS & TUBES (BELOW) FOR PROPER ASSEMBLY. IDLE LIMITER
CAP (72) CAN BE CAREFULLY PULLED OFF OF IDLE ADJ. NEEDLE.
(WILL BE USED OVER).

NOMENCLATURE

REF. NO.	REF. NO.
1. SCREW & LOCKWASHER- SOLENOID	36. FLOAT- MAIN
2. SOLENOID- FUEL CUT OFF	37. NEEDLE & SEAT ASSY- MAIN
3. O-RING- SOLENOID	38. PIN- AUX. FLOAT
4. COTTER PIN- DASHPOT ROD	39. FLOAT- AUXILIARY
5. WASHER- DASHPOT ROD	40. NEEDLE & SEAT ASSY.- AUXILIARY
6. BUSHING- DASHPOT ROD	41. GASKET- BOWL COVER
7. SCREW & LOCKWASHER (2)- DASHPOT BRACKET	42. JET- PRIMARY SLOW
8. DASHPOT & BRACKET ASSY.	43. JET- PRI. MAIN AIR BLEED
9. COTTER PIN- THROTTLE OPENER ROD	44. TUBE- PRI. EMULSION
10. WASHER- THROTTLE OPENER ROD	45. JET- SEC. MAIN AIR BLEED
11. BUSHING- THROTTLE OPENER ROD	46. TUBE- SEC. EMULSION
12. SCREW & LOCKWASHER (2)- THROTTLE OPENER BRACKET	47. JET- AUX. MAIN AIR BLEED
13. THROTTLE OPENER & BRACKET ASSY.	48. TUBE- AUX. EMULSION
14. COTTER PIN- CHOKE OPENER ROD	49. JET- AUX. SLOW
15. WASHER- CHOKE OPENER ROD	50. SCREW & LOCKWASHER (2)- MAIN JET COVER
16. BUSHING- CHOKE OPENER ROD	51. COVER- MAIN JET
17. SCREW & LOCKWASHER (2)- CHOKE OPENER ASSY.	52. O-RING- MAIN JET COVER
18. CHOKE OPENER ASSY.	53. JET- PRIMARY MAIN
19. O-RING- CHOKE OPENER ASSY.	54. O-RING- PRI. MAIN JET
20. COTTER PIN- SECONDARY DIAPHRAGM ROD	55. JET- SECONDARY MAIN
21. WASHER- SECONDARY DIAPHRAGM ROD	56. O-RING- SEC. MAIN JET
22. BUSHING- SEC. DIAPH. ROD	57. PLUG- AUX. MAIN JET
23. SCREW & LOCKWASHER (2)- SEC. DIAPH. ASSY.	58. O-RING- PLUG
24. SECONDARY DIAPHRAGM ASSY.	59. JET- AUX. MAIN
25. O-RING- SECONDARY DIAPHRAGM ASSY.	60. O-RING- AUX. MAIN JET
26. SCREW- PUMP LEVER	61. SCREW & LOCKWASHER (3)- COVER
27. WASHER- LEVER SCREW	62. COVER- PUMP DIAPHRAGM
28. PUMP LEVER & ROD ASSY.	63. SPRING- PUMP DIAPHRAGM
29. WASHER- LEVER SCREW	64. DIAPHRAGM- PUMP
30. LOCKWASHER- LEVER SCREW	65. O-RING- (2)- PUMP COVER SEAL
31. BOOT- PUMP PIN	66. COTTER PIN- AUX. THROTTLE LINK
32. PIN- PUMP DIAPHRAGM	67. WASHER- AUX. THROTTLE LINK
33. SCREW & LOCKWASHER (10)- BOWL COVER	68. SCREW & LOCKWASHER (5)- THROTTLE BODY
34. BOWL COVER ASSY.	69. BOWL ASSY.
35. PIN- MAIN FLOAT	70. O-RING- THROTTLE BODY
	71. SLEEVE- PRIMARY BORE
	72. CAP- IDLE LIMITER
	73. NEEDLE- IDLE ADJUSTING
	74. SPRING- IDLE ADJ. NEEDLE
	75. WASHER- IDLE NEEDLE
	76. O-RING- IDLE NEEDLE
	77. THROTTLE BODY ASSY.
	78. SCREW, AUX. IDLE MIXTURE # TURNS
	79. SPRING, AUX. IDLE MIX. SCREW
	80. WASHER, AUX. IDLE MIX. SCREW
	81. ORIG. AUX. IDLE MIX SCREW

CLEANING

CLEANING MUST BE DONE WITH CARBURETOR DISASSEMBLED.
SOAK PARTS LONG ENOUGH TO SOFTEN AND REMOVE ALL FOREIGN
MATERIAL. USE A CARBURETOR CLEANING SOLVENT. MAKE
CERTAIN THE THROTTLE BODY IS FREE OF ALL CARBON DEPOSITS.
WASH OFF IN SUITABLE SOLVENT. BLOW OUT ALL PASSAGES
AND JETS IN CASTINGS WITH COMPRESSED AIR AND CHECK
CAREFULLY TO INSURE THOROUGH CLEANING OF OBSCURE AREAS.
CAUTION: DO NOT SOAK DIAPHRAGM ASSEMBLIES (8) (13) (18)
(24), SOLENOID (2) FLOATS (36) (39) OR PARTS MADE OF
RUBBER IN ANY TYPE OF CLEANING SOLVENT.

REASSEMBLY

REASSEMBLE IN REVERSE ORDER OF DISASSEMBLY. NOTE SPECIAL
INSTRUCTIONS AND ADJUSTMENTS.

SPECIAL INSTRUCTIONS

IDLE ADJUSTING NEEDLE. (73)- TO INSTALL FIRST ASSEMBLE
SPRING (74), WASHER (75), O-RING (76) ONTO NEEDLE.
TURN NEEDLE IN UNTIL LIGHTLY SEATED THEN BACK OUT 2
TURNS. (DO NOT INSTALL IDLE LIMITER CAP AT THIS TIME.)

THROTTLE BODY ASSY. (77) WHEN INSTALLING IT TO BOWL ASSY.
BE SURE TO HOOK UP AUX. THROTTLE LINK.

SEC. MAIN JET (55)- BE SURE TO INSTALL IN CENTER HOLE.
END HOLE ON SECONDARY SIDE IS BLANK.

NEEDLE & SEAT ASSYS (37) (40)- AFTER FLOAT LEVELS HAVE
BEEN ADJUSTED BE SURE TO SEAL SCREW HEADS WITH AN EPOXY
SEALER TO PREVENT TURNING OF NEEDLE SEATS.

FLOAT PINS (35)(38)- BE SURE TO INSTALL WITH TAPERED END
TOWARDS CENTER OF BOWL COVER.

ADJUSTMENTS

NOTE: AFTER FLOATS OR ADJUSTED, SEAL TOP OF NEEDLE SEAT WITH A SEALER TO PREVENT TURNING.

TO ADJUST TURN NEEDLE SEAT.

NOTE: AFTER FLOATS OR ADJUSTED SEAL TOP OF NEEDLE SEAT WITH A SEALER TO PREVENT TURNING

①

BOWL COVER INVERTED, THEN TURN UP TO THE VERTICAL POSITION WITH FLOAT ARM PINS TO THE TOP. FLOAT RESTING LIGHTLY ON NEEDLE (WHICH IS SPRING LOADED.) DO NOT COMPRESS SPRING LOADED NEEDLE.

DRY FLOAT LEVEL ADJUSTMENT.

⑤ TO ADJUST BEND TAB.

FLOAT DROP ADJUSTMENT.

④ BOWL COVER IN THE SAME POSITION AS STEP 1. MEASURE DISTANCE BETWEEN STOP AND TAB ON FLOAT ARM.

1 MM CLEARANCE

33.5 MM
LARGE FLOAT

1 MM
CLEARANCE

② MEASURE DISTANCE FROM GASKET SURFACE OF BOWL COVER TO FLAT BOTTOM SURFACE OF FLOAT AT TOE END.

CAUTION: DO NOT EXERT PRESSURE ON RESILIENT NEEDLE VALVE.

⑤ 31 MM
SMALL FLOAT

