

English

Installation instructions

1. The cabin air filter is in the cowl.
2. Raise hood - look for the cabin air compartment in the cowl on the passenger side
3. Unsnap the cabin air cover - look for the lever on the left - push the lever out and remove the cabin air filter
4. Replace the filter by depressing the lever in the housing and sliding the filter into the track
5. Replace cover

Francais

Instructions d'installation

1. Le filtre d'habitacle est situé dans l'auvent.
2. Relevez le capot et repérez le boîtier du filtre d'habitacle dans l'auvent, côté passager.
3. Débranchez le couvercle du filtre – le levier se trouve sur la gauche – tirez sur le levier pour dégager le filtre d'habitacle.
4. Remplacez le filtre en appuyant sur le levier dans le boîtier et en glissant le filtre dans la coulisse.
5. Reposez le couvercle.

Español

Instrucciones de instalación

1. El filtro de aire de la cabina está situado en el panel protector del motor, en el capó.
2. Levante el capó. Busque el compartimiento de aire de la cabina en el panel protector del motor, en el lado del pasajero.
3. Desenganche la cubierta del filtro de aire de la cabina. Localice la palanca en la izquierda. Empuje la palanca hacia fuera y quite el filtro de aire de la cabina.
4. Reemplace el filtro, bajando la palanca en la caja y deslizando el filtro dentro de la guía.
5. Vuelva a colocar la cubierta.