

English

Installation instructions

Cabin filter is located under the hood and the housing is on the underside of the hood

1. Open hood
2. On both sides near the windshield, locate the cabin air housings on the underside of the hood (there are two).
3. Use a screw-driver to remove the screw holding the cover in place (near the edge of the housing) - open the covers downward
4. Remove the old filters and replace

Francais

Instructions d'installation

Les filtres d'habitacle sont situés sous le capot et leurs boîtiers sont placés sous le dessous du capot.

1. Ouvrez le capot.
2. Des deux côtés du pare-brise, repérez les boîtiers des filtres sous le dessous du capot (il y en a deux).
3. À l'aide d'un tournevis, déposez la vis retenant chaque couvercle en place (près du rebord du boîtier); ouvrez les couvercles vers le bas.
4. Retirez les filtres usés et remplacez-les par des filtres neufs.

Español

Instrucciones de instalación

Los filtros de aire de la cabina están situados debajo del capó, y sus cajas se encuentran en el lado inferior del capó.

1. Abra el capó.
2. En ambos lados del parabrisas, localice las cajas de los filtros de aire de la cabina, en el lado inferior del capó. (Hay dos.)
3. Utilice un destornillador para quitar el tornillo que sostiene cada cubierta en su lugar (cerca del borde de la caja). Abra las cubiertas hacia abajo.
4. Quite los filtros viejos y reemplácelos.