# EXPLANATION ABOUT HOW TO USE IGNITER MOUNTING SCREWS

The 4 x 10 mm screws are provided with the module. Use the screws as illustrated below.

1. For A type distributor: Use the 4 x 10 mm screws provided with the module. Discard old screws.
2. For B type distributor: Reuse old screw. Do not use the screws provided.
3. Apply grease to bottom of module.

