630442 ALT. B

INSTALLATION INSTRUCTIONS

The old unit, removed from your vehicle may have different wire color orientation than the enclosed new socket. To install the socket, follow these guidelines:

Turn on your park lights or headlights and locate the "hot" wire to be connected to the brown tail light wire of the new socket. Connect the black wire to the black wire of the wiring harness. Connect the orange stoplight wire to the remaining open wire.

MODE D'INSTALLATION

Il se peut que l'ancien modèle qui a été retiré du véhicule comporte des fils de couleurs différentes de ceux de la nouvelle douille. Pour installer la douille, suivre les instructions suivantes :

Allumer les feux de stationnement ou les phares et localiser le fil « sous tension » qui doit être raccordé au fil marron du feu de position arrière de la nouvelle douille. Raccorder le fil noir au fil noir du faisceau de câblage.
Raccorder le fil orange du feu de freinage au fil nu restant.

INSTRUCCIONES DE INSTALACIÓN

La unidad que se retira de su vehículo puede presentar una orientación de color diferente a la del nuevo adaptador provisto. Para instalar el adaptador siga los siguientes pasos:

Encienda las luces de estacionamiento o las luces delanteras y ubique el cable "caliente" que se debe conectar al cable marrón de las luces de posición del nuevo adaptador. Conecte el cable negro al cable negro del arnés de cables. Conecte el cable anaranjado de la luz de freno al cable abierto restante.