

English




Installation instructions

1. The cabin air filter is the cowl
2. Open hood
3. Pull back the rubber hood seal from the edge of the vent cover near the windshield on the passenger side
4. Remove the cabin air inlet panel
5. Release the tabs on each side of the cabin air access panel
6. Remove the cabin air filter by lifting Upward
7. Install a new filter
8. Replace the cover and inlet panel

Francais

Instructions d'installation

1. Le filtre d'habitacle est situé dans l'auvent.
2. Ouvrez le capot.
3. Détachez le joint de capot en caoutchouc du bord du couvercle de ventilation, près du pare-brise, du côté du passager.
4. Déposez le panneau d'admission d'air dans l'habitacle.
5. Détachez les pattes de chaque côté du panneau d'accès au filtre d'habitacle.
6. Retirez le filtre utilisé en le déplaçant vers le haut.
7. Installez un filtre neuf.
8. Reposez le couvercle et le panneau d'admission d'air.



Español

Instrucciones de instalación

1. El filtro de aire de la cabina se encuentra en el panel protector del motor en el capó.
2. Abra el capó.
3. Quite el sellado de goma del capó, del borde de la cubierta de la ventilación cerca del parabrisas, en el lado del pasajero.
4. Quite el panel de la entrada de aire de la cabina.
5. Libere las lengüetas en cada lado del panel de acceso al filtro de aire de la cabina.
6. Quite el filtro de aire de la cabina, llevándolo hacia arriba.
7. Instale un nuevo filtro.
8. Vuelva a colocar la cubierta y el panel de entrada de aire.