

English

Installation instructions

1. The cabin air filter is behind the glove box and it must be removed
2. Open the glove box and disengage the damper strap
3. Press on the sides of the glove box and lower it
4. Remove the cabin air cover by pressing both clips
5. Remove the cabin filter from the blower unit and replace it
6. Reattach cover and raise glove box into Position

Francais

Instructions d'installation

1. Le filtre d'habitacle est situé derrière la boîte à gants, qui doit être déposée.
2. Ouvrez la boîte à gants et dégagez la patte de l'amortisseur.
3. Appuyez sur les deux côtés de la boîte à gants et abaissez-la.
4. Déposez le couvercle du filtre d'habitacle en appuyant sur les deux attaches.
5. Retirez le filtre d'habitacle usé du bloc de ventilation et remplacez-le.
6. Reposez le couvercle et relevez la boîte à gants dans sa position habituelle.

Español

Instrucciones de instalación

1. El filtro de aire de la cabina está situado detrás de la guantera y la misma debe ser quitada.
2. Abra la guantera y libere la correa del regulador.
3. Presione sobre los costados de la guantera y llévela hacia abajo.
4. Quite la cubierta del filtro de aire de la cabina, presionando ambos sujetadores.
5. Quite el filtro de aire de la cabina, de la unidad del ventilador, y reemplácelo.
6. Vuelva a sujetar la cubierta y levante la guantera para llevarla a su posición.

