

English

Installation instructions

1. The cabin air filter is behind the glove box and it must be removed
2. Open the glove box then grab the top and bottom sections and gently pull the glove box door out from the housing to release it
3. Depress the cabin air filter cover retaining tabs, then remove the cover by pulling downward
4. Remove the cabin air filter and replace it
5. Replace the cover and reinstall the glove box

Francais

Instructions d'installation

1. The cabin air filter is behind the glove box and it must be removed.
2. Open the glove box then grab the top and bottom sections and gently pull the glove box door out from the housing to release it.
3. Depress the cabin air filter cover retaining tabs, then remove the cover by pulling downward.
4. Remove the cabin air filter and replace it.
5. Replace the cover and reinstall the glove box.

Español

Instrucciones de instalación

1. El filtro de aire de la cabina está situado detrás de la guantera y la misma debe ser quitada.
2. Abra la guantera, tome las secciones superior e inferior, y suavemente lleve la puerta de la guantera hacia afuera de la caja, para liberarla.
3. Deprima las lengüetas de retención de la cubierta del filtro de aire de la cabina, luego quite la cubierta, llevándola hacia abajo.
4. Quite el filtro de aire de la cabina y reemplácelo.
5. Vuelva a colocar la cubierta y vuelva a instalar la guantera.

