

English

Installation instructions

Cabin filter location # 2 – Under the hood and in the cowl

1. Open hood.
2. On the passenger side near the windshield, remove the cowl section – there are several retaining screws to remove.
3. Locate the cabin air filter cover – remove it – pull out the old filter and replace.

Francais

Instructions d'installation

Emplacement no 2 du filtre d'habitacle – Sous le capot et dans l'auvent

1. Ouvrez le capot.
2. Sur le côté du passager, près du pare-brise, déposez le couvercle d'auvent; il faut déposer plusieurs vis de retenue.
3. Déposez le couvercle du filtre d'habitacle; retirez le filtre usé et remplacez-le par un filtre neuf.

Español

Instrucciones de instalación

Ubicación n° 2 del filtro de aire de la cabina – Debajo del capó y en el panel protector del motor

1. Abra el capó.
2. En el lado del pasajero, cerca del parabrisas, quite la sección del panel protector del motor; hay que sacar varios tornillos de retención.
3. Localice la cubierta del filtro de aire de la cabina. Quítela. Quite el filtro viejo y reemplácelo.