

English

Installation instructions

The cabin air filter is located behind the glove-box and the glove-box must be removed.

1. Open glove box.
2. Press in on both sides of the glove-box to clear the stops and drop it down.
3. Locate the cabin air cover (right-side) – remove the retaining screws
4. Remove old cabin air filter and replace it.

Francais

Instructions d'installation

Le filtre d'habitacle est situé derrière la boîte à gants, qui doit être déposée.

1. Ouvrez la boîte à gants.
2. Appuyez des deux côtés de la boîte à gants pour dégager les butées et l'abaisser.
3. Repérez le couvercle du filtre d'habitacle (côté droit) et déposez les vis de retenue.
4. Retirez le filtre d'habitacle utilisé et remplacez-le par un filtre neuf.

Español

Instrucciones de instalación

El filtro de aire de la cabina está situado detrás de la guantera y la misma deberá ser quitada.

1. Abra la guantera.
2. Presione hacia adentro sobre ambos costados de la guantera, para liberar los topes y dejarla caer.
3. Localice la cubierta del filtro de aire de la cabina (lado derecho). Quite los tornillos de retención.
4. Quite el viejo filtro de aire de la cabina y reemplácelo.