

ENGLISH

Cabin Air Instruction Sheet - BMW 328

- 1.Open the hood and locate the cabin air housing near the firewall on the passenger side.
- 2.Remove the six bolts (8mm) from the cabin air housing.
- 3.Lift the cover off to expose the filter.
- 4.Remove the old filter and insert new filter.
- 5.Replace cover and tighten the bolts.

24255

14-1034734

FRENCH

Mode d'installation du filtre d'habitacle - BMW 328

- 1.Ouvrez le capot et repérez le boîtier du filtre d'habitacle près de la cloison pare-feu du côté du passager.
- 2.Déposez les six boulons (de 8 mm) du boîtier du filtre.
- 3.Relevez le couvercle pour exposer le filtre.
- 4.Retirez le filtre usé et remplacez-le par un filtre neuf.
- 5.Reposez le couvercle et serrez les boulons.

24255

14-1034734

SPANISH

Instrucciones para la instalación del filtro de aire de la cabina - BMW 328

- 1.Abra el capó y localice la caja del filtro de aire de la cabina, cerca de la barrera ignífuga, en el lado del pasajero.
- 2.Quite los seis pernos (8mm) de la caja del filtro de aire de la cabina.
- 3.Levante la cubierta para dejar el filtro expuesto.
- 4.Quite el viejo filtro e inserte un filtro nuevo.
- 5.Vuelva a colocar la cubierta y ajuste los pernos.

24255

14-1034734